

### YuMi: IRB 14000 Agenda

- Differentiated value proposition
- Overview and vision
- Main features
- Payload
- Working range
- Performance and accuracy
- Main dimensions
- Easy integration
- Outline manipulator

- Table mounting
- IP protection
- ESD protection
- Controller
- Customer benefits
- Key applications and segments
- Summary



# Overview Differentiated value proposition



No barriers, no cages, no zones, YuMi is the first truly collaborative robot solution.



#### Overview and vision

- The target is to make automation technically and economically feasible for small part assembly.
- The solution shall also be suitable for pre-processing, assembly and packaging of all 3C product and other small devices, e.g. digital cameras, toys, watches, ABB low voltage products.
- The automated cells will co-exist with manual assembly cells and interaction between manual and automated cells must be smooth and safe.
- The robot automation should in principle perform the same work as a skilled assembly worker.
- The robot automation shall be easy to adapt for new conditions and tasks.



# Overview and vision Demand from all industries

## Target Industry (Consumer)

- Small parts assembly
- 3C
- Consumer products
- Toy Industry
- Watch industry

#### **Market Demand**

- Cycle time performance
- Safe by design
- ESD compliance
- Work close with humans
- Easy to depoly/program

### Market Demand (continued)

- IP 30
- Accuracy and cost efficiency
- Size of human torso
- Portable

#### Most common feedback

- Fencing and saftey are a big part of the cell cost
- Must be able to assemble same parts in fast and accurate manner whilst been safe
- Need to be able to depoly and program



# Overview and vision Target growth markets







#### **Small Parts Assembly**

- Collaborative Assembly
- Camera-based inspection and assembly
- Accurate and fast assembly
- Testing and packaging

#### **Consumer Products**

- Collaborative Assembly (Plastic parts etc.)
- Packaging of small goods
- Multifunction hand for add components

#### **Toy Industry**

- Collaborative Assembly (toys)
- Use of feeding and vision options



# Overview and vision Filling a gap



Small IRBs	IRB 14000
<ul> <li>Our market in the Small Parts         Assembly, has reached great potentials         <ul> <li>Good market reputation</li> <li>Good performance in terms of accuracy and robustness</li> <li>One major drawback – working close to humans and collaboration</li> </ul> </li> <li>Aim of IRB 14000 is to fill this gap</li> </ul>	<ul> <li>Goal is to provide a solution to small parts assembly while providing a cost competitive offering like</li> <li>Inherent safety</li> <li>Flexible feeding parts management</li> <li>Vision-Guided Assembly</li> <li>Best in class accuracy</li> <li>Speed effective assembly</li> </ul>



### Overview and vision Leading the competition



- More compact than the competitors
- More precise
- Equipped with an enclosed controller
- Universal parts feeding system
- High-end camera part location
- State of the art motion control
- First safe robot by design




# Overview Current portfolio





### Overview and vision New era in our portfolio






### Main features

	IRB 14000 – 0.5/0.55	
Payload	0.5 kg per arm	
Reach	559 mm	
Accuracy	0.02 mm	
Footprint	399 mm * 497 mm	
Customer interface	Foot interface	
Weight	38 kg	
Mounting position	Table	
Temperature	5 C – 40 C deg	
IP Protection	IP 30	
Clean room / food grade	No	




# Payload IRB 14000 0.5/0.55









# Working range IRB 14000 0.5/0.55













# Working range: Single arm IRB 14000 0.5/0.55








# Working range Maximum velocity

	Motion Range	Max. Velocity
Axis 1 Rotation	+168.5° to -168.5°	180 °/s
Axis 2 Arm	+43.5° to -143.5°	180 °/s
Axis 7 Rotation	+168.5° to -168.5°	180 °/s
Axis 3 Arm	+80° to -123.5 °	180 °/s
Axis 4 Wrist	+290° to -290 °	400 °/s
Axis 5 Bend	+138° to -88°	400 °/s
Axis 6 Turn	+229° to -229 °	400 °/s




# Main dimensions IRB 14000 0.5/0.5








# Main dimensions IRB 14000 0.5/0.5





# Easy integration I/O: Customer interfaces






### Easy integration Customer interfaces






# Easy integration I/O: Customer interfaces






# Easy integration I/O: Customer interfaces





### Easy integration Mounting interfaces





A 8 pad Millmax connector for 24V and Ethernet or IO

7.5e8 and 4.4F10 for air


15H7 for alignment


2E8 pin hole for alignment

4 x 2.9 thru holes for M2.5 screws



# IRB 14000 0.5/0.55 vs IRB 1200-7/0.7 Outline manipulator










**Front view** 

**Side view** 

**Top view** 



## YuMi: IRB 14000 Table mounting





### IP protection








#### IP 30 (Standard)

It is sufficient for assembly



## **ESD** protection





### YuMi: IRB 14000 Controller



- Embedded controller based on IRC5
- Portable (38kg)
- External connectors
- Built-in 8 in /8 out





- Padded arms Including internal wiring and air
- Integral controller New in ABB portfolio
- Light construction –
   Makes the robot portable
- Ease-of-use— Lead Through Programing
- Enclosed design –
   Lower maintenance
- Wide range of communications options – easy to interface

- High speed 1500mm- ROI is increased
- Dual arm Multi-tasking
- Integrated vision Built in to product
- ESD compliance Can work with open electronics
- Safety certified Certified by an independent body
- Integrated hand Easy to integrate





#### **Padded arms**

- Adds to safety of operators if there is an unlikely contact during operation
- The robot can be run faster due to added protection
- Faster robot means the ROI will be greater





#### Integral controller

- Saves working space
- Better cell layout
- Equipment can be placed closer to, or around, robot without interference
- Robot is more streamlined and easy to relocate
- No floor cables or control cables





#### **Lightweight construction**

- Makes the robot portable
- Added to safety of the robot
- Smaller frame to mount the robot







#### Ease-of-use

- Lead-Through Programming makes the programming easy
- Integrated vision can pick unsorted parts
- Tablet programming can be wireless saving the need for wires
- Standard IRC5 rapid as other ABB robots





# Enclosed design, which allows all wiring and air to go through the inside of the robot

- Reduced maintenance
- Less risk of cable and air hose damaged
- Can be used in confined spaces
- Easy to keep clean
- No risk of dust collecting on cables







# Wide range of communications options

- No problem to connect other devices
- Not locked into one option
- Pick your standard so you do not have to train your staff






# Best in class 1500 mm/sec collaboration speed

- Higher output, increases productivity
- Speed and safety at the same time
- Cutting-edge design standards







#### **Dual arm**

- Possible to achieve contact force assembly between arms
- Can process two tasks at the same time
- Operation similar to a human assembling





#### **Integrated vision**

- Cameras embedded in gripper
- Integrated hands makes it possible to use the hand for vison guided
- Can be used for simple inspection





#### **ESD** compliance

- No problems with static discharge
- Perfect for electronic assembly
- No need to test as we have certified the robot



# FUNCTIONAL SAFETY



#### Safety certified

- No need to certify the robot
- Can be included in your risk assessment of the cell
- Independent body has certified the robot
- PL b Cat b





#### **Integrated hand**

- No need to design your own hand
- Multi-option hand with five options
- Integrated communications and air
- Servo
- Vacuum
- Camera



- Applications
  - Be suitable for
    - Small Parts Assembly
    - Collaborative Assembly
    - Accurate and fast assembly
    - Testing and packaging
  - Be not suitable for
    - Paint
    - Food grade
    - Clean room

#### Segments

- Electronics assembly
  - Collaborative Assembly
  - Packaging of small goods
  - Multi-functional hand for odd sized components
- Toy industry
  - Collaborative Assembly
  - (plastics)
  - Use of feeding and vision options



### Key applications and segments Assembly



#### **Small Parts Assembly**

- IRB 14000 is the perfect alternative/complementary for IRB 120 or IRB 1200 in small parts assembly
- Safe collaborative assembly
- Precise 0.02 repeatability for small tasks





#### **Vision Guided-Assembly**

- Vision included in hands as package
- Vision can also be connected to robot for external devices like flex feeders
- This makes it possible to have less jigging and move to a more flexible cell design





# Small Parts Assembly using the FlexFeeder™s and ABB gripper

 Gripper and FlexFeeders make it possible to have a complete solution from part handling to assembly



 Odd sorted parts can be placed in FlexFeeders and presented to the robot in a two dimensional plane







#### **Small Parts Material Handing**

- After the assembly process is complete the robot can place the finished product in box ready for shipment
- YuMi working side-by-side handing finished parts to be packed



### Summary



#### Safe and collaborative

- No cages needed
- Padded arms and light weight design
- Speed limited

#### **Increased ROI**

fast accurate assembly, lower maintenance costs

#### **Ease-of-integration**

- Wide range of communications interfaces
- Integrated hand equipped with vision
- Integrated controller
- Light weight and portable

#### Ease-of-use

Lead-Through Programming



# Power and productivity for a better world™

